
AUTOMATIC WELD SIZE GAUGE




For Accurate Calibration of **Butt and Fillet Type Welds**

1. To Determine the Size of a Fillet Weld




Place the gauge against the toe of the fillet weld and slide pointer out until it touches structure as shown. Read "Size of the Fillet Weld" on the face of gauge as indicated by arrow.

2. To Check the Pemissible



After the size of a convex weld has been determined, place the gauge against the structure and slide pointer until it touches face of fillet weld as shown. The maximum convexity should not be greater than indicated by "Maximum Convexity Scale" as indicated by arrow for the size of fillet being checked.

Tolerance of Convexity



With the new improved A.W.S. Gauge shown above it is possible to meet specifications of butt and fillet type welds. New redesigned instrument is pocket sized and easy to operate, new feature includes thumb screw which replaces old hard to operate rivet

Diagrams at left illustrate the ease with which welders and inspectors may accurately check sizes of convex or concave fillets as well as butt weld rein-


The convexity and concavity sizes have automatically been predetermined in accordance with American Welding Society DI.I. Paragraph 3.6.

Instrument is precision built of stainless steel with dimensional readings chemically etched and filled for easier reading.

> Part No. GAL-6 **GAL-6M**

Description **Standard Gauge Metric Gauge**

3. To Check the Permissible **Tolerance of Concavity and** Underfill



Place gauge against structure and slide pointer out until it touches the face of the fillet weld as shown. If the pointer does not touch as shown, the fillet requires additional weld metal.

4. To Check the Permissible Tolerance of Reinforcement



Place gauge so that reinforcement will come between legs of gauge and slide pointer out until it touches the face of weld as shown.

G.A.L. GAGE PAGE 6 © June 2000