

Thermistor Instruments

SH66A 3 Zone Temperature Instrument

For applications when multiple temperature measurements are needed, this is the instrument to use. Features include a backlit display for dark environments, sealed keypad which protects the instrument from spills and dust, and a battery eliminator jack. Simultaneously measure suction and liquid line temperatures, as well as temperatures across condensing coils, evaporator coils and ambient temperatures. View temperature differential between zones 1 and 2 and review Min / Max temperatures from all three zones.

SH66A Includes

- 1075 General Purpose Probe
- 2010 Air Probe
- 4011 Pipe Strap Probe



SRH77A 3 Zone Temperature / Humidity Instrument

When temperature and relative humidity measurements are critical, the SRH77A is the expert's choice. Features include a backlit display for dark environments, sealed keypad which protects the instrument from spills and dust, and a battery eliminator jack. View temperature differential, %RH, and wet-bulb. You will find this to be an accurate and fast service tool. The bright blue rugged carry case makes this tool easy to find when on location, or in the back of a service truck.

SRH77A Includes

- 1075 General Purpose Probe
- 4011 Pipe Strap Probe
- 5028 Slim Humidity Probe



4005I Cordless Pipe Clamp Temperature Instrument

Includes 2.5" / 63.5 mm Retractable General Purpose Probe. Measure temperature of pipes up to 1-3/8" / 34.9 mm diameter.

- Single-Handed Use
- Spring-Loaded to Ensure Repeatability
- Auto Shut-off after 5 Minutes of Non-use
- Mode Button: Hold, Max & Min
- 4005I Nylon Belt Pouch included

