

## mini-Ligno DX/C



The DX/C comes highly recommended by independent trade magazines for its accuracy, convenience and external probe capability. The DX/C combines all advantages of our pocket-size mini-Ligno meters and more:

- a perfectly designed case with built-in pins
- a wide measuring range for wood
- built-in corrections for 20 wood groups
- large display with easy-to-read numbers
- reference scale for non-wood building materials
- available with connector for external electrode or in-kiln probes, see >> DX/C Packages

### Specifications and Description: mini-Ligno DX/C

|                             |   |
|-----------------------------|---|
| <b>Measuring Range:</b>     | 5-65% dependent upon species setting*   |
| <b>Resolution:</b>          | 0.1% for values below 10% and 1% steps above 10%                                      |
| <b>Species Corrections:</b> | 20 settings for wood species corrections with chart for domestic and tropical species |
| <b>Reference Scale:</b>     | 0-99 for non-wood building materials  |
| <b>Pins:</b>                | 2 pair of pins, measuring depth of 3/16" and 7/16" (5,10mm)                           |
| <b>Battery</b>              | 8 ounces (200g), made out of high-impact plastic                                      |
| <b>Size :</b>               | pocket-size 2 3/4"x 5"x1" (70x140x25mm)   |
| <b>Weight:</b>              | 8 ounces (200g), made out of high-impact plastic                                      |
| <b>Accessories:</b>         | Connection for external electrode, 2 pair of pins, wrist strap and pouch and battery  |



The DX/C is one of our most popular meters with the following features:

- a unique shape that fits comfortably in your hand when measuring
- a measuring range low enough to check hardwood floors (5%\*)
- a measuring range high enough to evaluate wet lumber (65\*)
- a bright, digital display readable even in dark crawl spaces
- resolution of 0.1% below the critical range of 10%
- 20 settings for wood species corrections including a chart for domestic and tropical wood species
- a reference scale 0-99 for non-wood building materials such as drywall, plaster and other "soft" building materials. For instance, to pinpoint problems around windows or showers, in leaky ceilings, after water lines broke or buildings were flooded.
- connection for external cables and electrode -- to evaluate concrete or reach hidden areas for moisture testing, even behind 7" of insulation.

For more options see >> Packages with mini-Lignos.

The functionally designed mini-Ligno DX/C fits in your hand when measuring and is small enough to carry in a shirt-pocket. The green cap covers the pins during transportation and serves as a handle when pushing the pins into the wood. This unique design allows pushing behind the entire meter to insert the tapered pins easily. Longer pins are stored inside the meter for measuring thicker material. The short pins are ideal for surface or end cut readings and for veneer.

For measurements, push the pins into wood. The unique on-off switch between the pins, turns meter on automatically and bright LED lights instantly indicate moisture percentage.

An easy-to-use, reliable instrument.