

## mini-Ligno E/D



The mini-Ligno E/D moisture meter has a bright, easy-to-read, digital display and a wide moisture range - at an affordable price. Great for occasional use or in-line measurements. The moisture range is low enough for cabinet makers, professional woodworkers and hardwood floor installers and high enough for construction lumber, wood turning, pallet making, forest fire prevention and testing of firewood.

If an external electrode is required, see mini-Ligno DX/C, Lignometer K or Ligno-DuoTec.

### Specifications and Description: mini-Ligno E/D

<b>Measuring Range:</b>	6-45%
<b>Resolution:</b>	0.1% for values below 10% and 1% steps above 10%
<b>Species Corrections:</b>	2 settings for wood species corrections with LED indicator
<b>Pins:</b>	2 pair of pins, measuring depth of 3/16" and 7/16" (5,10mm)
<b>Battery</b>	8 ounces (200g), made out of high-impact plastic
<b>Size :</b>	pocket-size 2 3/4"x 5"x1" (70x140x25mm)
<b>Weight:</b>	8 ounces (200g), made out of high-impact plastic
<b>Accessories:</b>	wrist strap and pouch, battery and 2 pair of pins



The mini-Ligno E/D has the following features:

- a unique shape that fits comfortably in your hand when measuring
- a measuring range low enough to check hardwood floors (6%)
- a measuring range high enough to evaluate wet lumber (45%)
- a bright, digital display readable even in dark crawl spaces
- resolution of 0.1% below the critical moisture range of 10%
- 2 settings for wood species corrections

If you want to add an external probe, select the mini-Ligno C, mini-Ligno E/C or the mini-Ligno DX/C. For more options see >> Packages with mini-Lignos.

The functionally designed mini-Ligno E/D fits in your hand when measuring and is small enough to carry in a shirt-pocket.

The green cap covers the pins during transportation and serves as a handle when pushing the pins into the wood. This unique design allows pushing behind the entire meter to insert the tapered pins easily. Longer pins are stored inside the meter for measuring thicker material. The short pins are ideal for surface or end cut readings and for veneer.

For measurements, push the pins into wood. The unique on-off switch between the pins, turns meter on automatically and bright LED lights instantly indicate moisture percentage.

An easy-to-use, reliable instrument.